

Place the fuel pump access cover down and using a straight edge, square up the cover to the bolt shown in the picture. Once you have squared the cover up, using a marker, trace around the cover.



Now trace a 5/8" border within the box you just traced. The seal can be used to help mark the inner boarder. Once you have the inner boarder traced out, you can now cutout the inner square. Please pay attention to the picture and the location of the wires and fuel line. The hole are predrilled in the access cover as well. A 7/32 drill bit can be used to drill the holes into the car. With the holes drilled, you can now lay the seal down and install the cover using the supplied self-tappers. Please note: the cover will not sit flush until you make your cut.

