

Fenfabrication 2020+ Diffy Stiffy Brace Instructions

1. Remove the lower 2 diff cover bolts on the passenger side using an e18 inverted torx then install the brace using the provided washers between the brace and diff and the polyurethane between the brace and the subframe.



2. Once the brace is tighten to the diff, a 3/8 drill bit can be used to drill the holes into the subframe. The brace can be used as a guide. Keep the polyurethane installed so your holes can all be drilled at once.



3. Slide the provided nuts up into the subframe through the existing holes and start the bolts to hold the brace to the subframe.

4. Loosen the diff bolts holding the brace to the diff then tighten down the bolts holding the brace to the subframe. Once they are right, torque back down the diff cover bolts and you are all set.