

Fenfab 2020+ BOV kit Instructions

1. Remove Driver side upper charge pipe between the intercooler and throttlebody.
2. Install Fenfab charge pipe. Please note it maybe easier to preinstall the BOV before installing the charge pipe.
3. Remove the stock BOV. With the stock BOV removed, install/seat the rubber plug inside the oem BOV flange and bolt down the BOV delete cover. (If you have the 21+ with no BOV, skip this step)
4. For vacuum line install/routing, please refer to the picture below:



5. Now to wire up the BOV delete resistor. The resistor can be soldered or the wires can be slid into the OEM pins on the BOV connector then tapped up. Please note polarity does not matter for wiring in the resistor. (If you have the 21+ with no BOV, skip this step)

If you have any question, please email support@fenfabrication.com