

# 25+ Explorer ST Intercooler Adapter Install Instructions

For best results, install the adapter onto the intercooler first.

- 1 Slide the adapter fully onto the intercooler outlet until it is completely seated.
- 2 Once seated, gently pull the adapter slightly toward the rear of the vehicle. This helps position the rear lip of the adapter securely against the intercooler lip.
- 3 Install and tighten the T-bolt clamp onto the adapter.
- 4 Insert the charge pipe into the adapter. **Do not bottom the charge pipe out against the intercooler outlet**, as this can place unnecessary stress on the connection and may lead to failure.
- 5 Once properly positioned, tighten the T-bolt clamp securely.
- 6 The adapter installation is now complete.